

NEW JERSEY DEPARTMENT OF ENVIRONMENTAL PROTECTION

Quarterly Physical Connection Test & Maintenance Report

Q 4/1: BSDW-QPCTMR 01/0 Date of T 0	2nd 3rd 2uarter Quarter Quarte	er Quarter 1 1/1-3/31	approved valve. Local Administr Inspection perfo kept at the facili submitted with the	It is to be mailed to the rative Authority within rmed by a Certified Testy and be exhibited up	eted for each test of each ne Supplier of Water and n 5 Days of each test & ster. These forms shall be on request, and are to be n Renewal Application.	
	nnection Permit No	ice identified below ha	as been tested and		uired by N.J.A.C.	
Manufacturer of Model Number	Description of Valve of Valve rl	RPZ DCVA	ompnance with th	is regulation. <u>Location of Valve</u>	<u> </u>	
	PI	RESSURE TEST	INTERNAL INSPECTION			
	REDUCED PRESSURE ZONE AS DOUBLE CHECK VALVE		SEMBLY	DOUBLE CHECK VALVE ASSEMBLY		
	1 ST Check	2 nd Check	Relief Valve	1 ST Check	2 ND Check	
Initial Test Passed Failed	Closed Tight atpsid Leaked No. 2 Shut-off Valve Leaked Leaked	Closed Tightpsid	Opened atpsid Did Not Open	OK Failed	OK Failed	
Repairs & Materials Used						
Test After Repair & Assembly	Closed Tightpsid	Closed Tightpsid	Opened atpsid	ок 🗆	ок 🗆	
•	hown Above are Certi	fied to be True.	W	itnesses to test &	Inspection	
Certified Testers	rtified Testers Name Nar		e <u>Title</u>			
Certified Testers	Signature	<u>Rep</u>	oresenting			
Certifying Authority			Name Title			
Cert. ID#	Expiration Date	/ / <u>Repr</u>	esenting			

<u>Test Procedure for Backflow Preventer Valve Assembly</u> <u>Set Up Procedure for Testing</u>

- 1. Verify that upstream shut-off valve No. 1 is open, and there is water pressure. Close downstream shut-off valve No. 2. <u>Note for Reduced Pressure Zone Valves:</u> A discharge from the relief port indicates a leaking No. 1 check valve. If there is no discharge No. 1 check can be assumed to be holding tight.
- 2. Flush test cocks Nos. 2, 3 & 4.

3. Close Test Kit high valve (A) and low valve (B), leave vent valve (C) open. BSDW-OPCTMR

Reduced Pressure Zone Valve Assembly Test

A) Test the **first check valve** for tightness at a minimum of 5 PSID of static pressure:

- 1. Connect high-pressure hose to test cock #2.
- 2. Connect low-pressure hose to test cock #3.
- 3. Open test cocks #2 & #3.
- 4. Open test kit high valve (A) and bleed air and water through vent hose... Close high valve (A).
- 5. Open test kit low valve (B) and bleed air and water through vent hose... Close low valve (B) **Slowly**.
- 6. Observe stable differential pressure on gauge and record on test form. (Must be 5 PSID Minimum)

B) Test the **second check valve** for tightness against backpressure:

- 1. Connect vent hose to test cock #4.
- 2. Open test cock #4.
- 3. Open test kit high valve (A)... Slowly.
- 4. Observe gauge and record on test form. Second check is tight if differential pressure drops slightly and holds steady. If pressure continues to drop until relief port discharges second check is leaking.

C) Test **No. 2 shut-off valve** for tightness:

- 1. Close test cock #2.
- 2. Observe gauge, if #2 shut-off valve is tight gauge will hold steady, if leaking the differential pressure will fall. Record result on form.

<u>Note:</u> If No. 2 shut-off valve is leaking tests **A & B are invalid**, since the valve is not in a static condition. Another shut-off valve downstream or a temporary by-pass from test cock #1 to test cock #4 must be utilized.

D) Test the operation of the **differential pressure relief valve:** Relief valve must open at a minimum of 2PSID below inlet.

- 1. Open test cock #2, test kit high valve (A) shall remain open and close test kit vent valve (C).
- 2. **Slowly** open the test kit low valve (B) until the differential pressure begins to fall... **Slowly.**
- 3. Observe the relief valve port for the first discharge of water and record the pressure differential on the gauge at this point on the form.

A) Test the **first check valve** for a minimum of 1 PSID of static pressure drop:

Double Check Valve Assembly Test

- 1. Connect high-pressure hose to test cock #2.
- 2. Connect low-pressure hose to test cock #3.
- 3. Open test cocks #2 & #3.
- 4. Open test kit high valve (A) and bleed air and water through vent hose... Close high valve (A).
- 5. Open test kit low valve (B) and bleed air and water through vent hose... Close low valve (B) **Slowly**.
- 6. Observe stable differential pressure on gauge and record on test form. (Must be 1 PSID Minimum)

B) Test the **second check valve** for a minimum of 1 PSID static pressure drop: (close test cocks #2 & #3 and remove high & low-pressure hoses)

- 1. Connect high-pressure hose to test cock #3.
- 2. Connect low-pressure hose to test cock #4.
- 3. Open test cocks #3 & #4.
- 4. Open test kit high valve (A) and bleed air and water through vent hose... Close high valve (A).
- 5. Open test kit low valve (B) and bleed air and water through vent hose... Close low valve (B) **Slowly**.
- 6. Observe stable differential pressure on gauge and record on test form. (Must be 1 PSID Minimum)

C) Test **No. 2 shut-off valve** for tightness:

- 1. Repeat procedure for test A.
- 2. Connect vent hose to test cock #4.
- 3. Open test cock #4.
- 4. Open test kit high valve (A) **Slowly**.
- 5. Close test cock #2.
- 6. Observe gauge, if #2 shut-off valve is tight gauge will hold steady, if leaking the differential pressure will fall. Record result on form.

<u>Note:</u> If No. 2 shut-off valve is leaking tests **A & B are invalid;** since the valve is not in a static condition. Another shut-off valve downstream or a temporary by-pass from test cock #1 to test cock #4 must be utilized.